



Cones/markers should be 30 feet apart.

Camera positioned as indicated on pattern drawing.

An additional helper, inspection judge, will be needed for the inspection, stepping to the right and walking counter-clockwise around the horse. The position of the inspection judge is marked by the X on the pattern. (behind the camera operator)

1. Start at cone 1.
2. Walk to cone 2.
3. Perform 360 degree pivot to the right.
4. Trot to cone 3.
5. Set up for inspection. (Not the camera operator)
6. After inspection, pivot 90 degrees to the right
7. Walk 10-12 feet. Stop. Pet your horse to indicate pattern is over.